



Ford Transit Side Door Van Step Install Instructions



1. Simple (4) bolt installation in van's side step well.
2. Red circled 5/16 bolts (4) are provided and install into existing factory-provided holes with (4) underbody backing plates (provided) for strength.
3. Install and tighten the mounting plate using the holes in steps 1.
4. Attach the step to the mounting plate using the provided quick-release pins.

Please contact us by phone or email with any questions or concerns during installation.

(763) 762-3451

sales@nationalfleetproducts.com